

Ulti-matte concealer
Light shade
2739-4.01



+ High coverage

+ Ultra matte

+ No setting powder needed

Phase	Name	INCI	Supplier	%
A	EMULIUM® ILLUSTR0	POLYGLYCERYL-6 POLYHYDROXYSTEARATE, POLYGLYCERYL-6 POLYRICINOLEATE, POLYGLYCERIN-6	Gattefossé	3.50
	LEXFEEL™ N5 MB	DIHEPTYL SUCCINATE, CAPRYLOYL GLYCERIN/SEBACIC ACID COPOLYMER	Inolex	7.00
	LIPOCIRE™ A SG	C10-18 TRIGLYCERIDES	Gattefossé	2.00
	PRESERVATIVE	PRESERVATIVE	-	1.00
B	BENTONE GEL NGD V	NEOPENTYL GLYCOL DIHEPTANOATE, DISTEARDIMONIUM HECTORITE, PROPYLENE CARBONATE	Elementis	5.00
	AEROSIL 200	SILICA	Evonik	1.00
C	UNIPURE WHITE LC 981 HLC	TITANIUM DIOXIDE, HYDROGENATED LECITHIN	Sensient	24.26
	UNIPURE YELLOW LC 182 HLC	CI 77492, HYDROGENATED LECITHIN	Sensient	0.63
	UNIPURE RED LC 381 HLC	CI 77491, HYDROGENATED LECITHIN	Sensient	0.08
	UNIPURE BLACK LC 989 HLC	CI 77499, HYDROGENATED LECITHIN	Sensient	0.03
	CETIOL® CC	DICAPRYLYL CARBONATE	BASF	14.00
	EMULIUM® ILLUSTR0	POLYGLYCERYL-6 POLYHYDROXYSTEARATE, POLYGLYCERYL-6 POLYRICINOLEATE, POLYGLYCERIN-6	Gattefossé	0.50
D	DEMINERALIZED WATER	WATER	-	32.00
	MAGNESIUM SULFATE (99%)	MAGNESIUM SULFATE	-	2.00
	SODIUM CHLORIDE, CODEX	SODIUM CHLORIDE	-	1.00
	GLYCERIN	GLYCERIN	-	2.00
E	SERICA 5	MICA	Sensient	1.00
	AMIHOPE® LL	LAUROYL LYSINE	Ajinomoto	1.00
F	GATULINE® LINK'N'LIFT	FRUCTOSE, GLYCERIN, AQUA, AESCULUS HIPPOCASTANUM (HORSE CHESTNUT) EXTRACT	Gattefossé	2.00
				100.00

Operating instructions

- In the main vessel, heat phase A at around 45°C to melt Lipocire™ A SG.
- Add ingredients of phase B one by one and disperse with Ultra Turrax for 5 minutes. Check that everything is dispersed homogeneously.
- Prepare the pigment phase C: wet pigments with Cetiol® CC and Emulium® Illustro and use a three roll mill to get a homogeneous paste. Add then to phase A+B and disperse the pigment paste with high shear or Ultra Turrax.
- Prepare water phase D and solubilize the electrolytes. Heat at 45°C.
- Proceed with the emulsion of phase D into phase A+B+C at 45°C under medium shear, and then increase to high shear (3000 rpm) for 10 minutes.
- Cool down under moderate shear and below 35°C add the powders of phase E. Mix under moderate shear for 5-10 minutes.
- Add then phase F.

Ulti-matte concealer
Light shade
2739-4.01



+ High coverage

+ Ultra matte

+ No setting powder needed

Description

Say bye-bye to dark circles with this high covering concealer! The texture doesn't move throughout the day thanks to its matte finish. This formula has been developed in 3 shades, from a very light to a very dark shade, so you can create a full range of colors without any trouble thanks to **Emulium® Illustro** pigment affinity. The yellow/warm undertones inside ensures perfect coverage of "purple" dark circles (based on colorimetry rules).

Specifications

+ Aspect:
Liquid beige emulsion

+ Viscosity Brookfield RV (spindle B, speed 5):
approx. 39200 mPa.s after 24h

+ >97% natural origin (ISO 16128)

Ingredients

- **Emulium® Illustro** is a natural origin W/O emulsifier that gives its pleasant sensory to the formula, and of course its stability. Here in the formula, it has two functions: emulsifier, and it is also used as a wetting agent in order to disperse the very high percentage of pigment, thanks to its excellent pigment compatibility.
- The balance between the emollients Cetiol® CC and LexFeel™ N5 MB plays an important role in the sensory of the formula. Those emollients have a good compatibility with **Emulium® Illustro**.
- **Lipocire™ A SG** improves the formula's creaminess and comfort.
- Bentone Gel® NGD V and Aerosil® 200 ensure rheological control and suspension of pigments/powders.
- Unipure HLC are hydrogenated lecithin coated pigments that have a very good affinity with W/O emulsions made with **Emulium® Illustro**.
- Magnesium Sulfate (99%) and Sodium Chloride are electrolytes put in aqueous phase to avoid Ostwald ripening.
- Amihope LL is a powder that provides a soft and silky feel.
- Serica 5 powder gives a silky touch to the formula and an illuminating effect.
- **Gatuline® Link'n'Lift** is an extract of horse chesnut flower that targets all eye contour wrinkles.