



+ Solid format

+ Monodose

+ DIY

Phase	Name	INCI	Supplier	%
A	EMULIUM® KAPPA MB	CANDELILLA/JOJOBA/RICE BRAN POLYGLYCERYL-3 ESTERS, GLYCERYL STEARATE, CETEARYL ALCOHOL, SODIUM STEAROYL LACTYLATE	Gattefossé	6.0
	GELEOL™ MB	GLYCERYL STEARATE	Gattefossé	21.5
	KAHLWAX 6607L	HELIANTHUS ANNUUS (SUNFLOWER) SEED WAX, ASCORBYL PALMITATE, TOCOPHEROL	Kahl	2.5
	ACTICIRE® MB	JOJOBA ESTERS, HELIANTHUS ANNUUS (SUNFLOWER) SEED WAX, POLYGLYCERIN-3, ACACIA DECURRENS FLOWER WAX	Gattefossé	1.0
	NOMCORT HKG	GLYCERYL BEHENATE/EICOSADIOATE	Nisshin Oillio	1.0
	PRESERVATIVE	PRESERVATIVE	-	0.8
B	SURFHOPE C-1616	SUCROSE PALMITATE	Mitsubishi-Kagaku Foods	3.6
	HYDRAMOL TGL	POLYGLYCERYL-3 LAURATE	Lubrizol	6.0
	DEMINERALIZED WATER	WATER	-	12.6
C	MOD MB	OCTYLDODECYL MYRISTATE	Gattefossé	22.0
	UNIFILMA HVY	DEXTRIN ISOSTEARATE	Miyoshi	1.5
D	SILICA BEADS SB-700	SILICA	Miyoshi	17.5
E	MICA BLACK	MICA, IRON OXIDES, TITANIUM DIOXIDE	Merck	2.0
F	HEMA' TITE™	HEMATITE EXTRACT	Gattefossé	2.0

Operating instructions

- Prepare A and heat to 85°C.
- Prepare B: weigh Surfhope C-1616 and add Hydramol TGL, mix until homogenization, then add water and heat to 75°C.
- Prepare C and heat to 75°C under mixing for about 20-25 min until homogenization.
- Add C to A.
- Under rapid mixing (3000 rpm), add B to A+C and mix for about 10 min.
- Add D, E and F and pour at around 50°C.



+ Solid format

+ Monodose

+ DIY

Description

These surprising solid black pellets are perfectly adapted to travel! One pellet represents a unique dose of a product, making it possible to take only the needed quantity. First, crush a pellet of the Magma Mask in your palm, then take a bit of the "Everything Balm", another Gattefossé formula (or alternatively hot water). Mix to form a thick black mask to spread directly onto the skin and rinse after 10 minutes.

Specifications

+ Aspect:
Black pellets

+ 98% natural origin (ISO 16128)

Ingredients

- **Emulium® Kappa MB**, used at 6%, creates an homogeneous texture and facilitates rinsing.
- **Geleol™ MB** is a co-emulsifier that helps to stabilize the formula and create a not-too-hard solid texture.
- Kahlwax 6607H is a hydrolyzed wax that brings consistency to the formula while facilitating rinsing.
- **Acticire MB®** is a texturing ingredient that brings moisturization and comfort.
- Nomcort HKG is an oil gelling agent that improves stability.
- **MOD MB** is an emollient that improves product spreadability once the mask is formed.
- Unifilma HVY is a film former that is used for its oil gelling properties to stabilize the formula.
- Surfhope C-1616 is a surfactant that facilitates rinsing.
- Hydramol TGL is a foam booster.
- Silica is used to trap bubbles once they are formed to maintain a thick foam.
- **Hema'Tite™** is an extract of hematite stone rich in iron with a retinol-like activity.